



Ezi-action® 25/5 Drumpump

Standard Features include:

- Polypropylene and polyethylene construction – chemical resistant.
- True double action pump – innovative, easy, patented pumping technology.
- Delivers on both the up and down stroke – continuous fast flow.
- Anti-pumping/safety device – deters access by children and unauthorised personnel.
- Pumps from base of container – all contents emptied.
- Unique Ezi-action® Adaptor fittings – leak free, secure fit.
- Constructed from FDA compliant plastics – confidence with liquid food products.
- 24 month manufacturer's warranty – high quality construction.
- Fully serviceable – dispense container after container, year after year.
- Spout style – extender hose can be attached to outlet spout.

Technical data

Style		Output per stroke	Maximum depth neck to bottom
25/5 (For 25 litre (5 gallon) containers) (Also suitable for 20 and 30 litre (8 gallon) containers)		160ml (6oz)	420mm (16 1/2 inches)
Width of spout	Length of Spout	Width of case pipe	Ezi-action® Adaptor Fitting*
20mm (Spout opening fits 25mm (1 inch) diameter extender hose)	160mm (6 inches)	41mm (1 1/2 inches)	C57, C63 (Europe) C69 (USA) C55, C63 (Australia, NZ) * Fittings for all container styles available
Packaging	Weight per pump	Outer carton contents	Outer carton dimensions
Each pump packaged in a plastic bag with a header card incorporating instructions stapled to the top.	400gms (.9lbs)	20 pumps	1170 x 300 x 270 mm 7kg 0.095 cubic metres

NZ Pump Company Ltd
21 Tawn Place
Hamilton 3200
New Zealand

Phone: +64 7 839 3838
Fax: +64 7 839 1193
E-Mail:
pacificsales@nzpump.com

New Zealand Pump Company Inc
801 South Palm Avenue,
Alhambra, CA 91803, USA

Phone: +1 626 458 8023
Fax :+ 1 626 458 8024
Email:
sales@nzpump.com

NZ Pump Company (Europe) Ltd
Unit 5/6 Greenline
Business Park
Wellington Street
Burton-on-Trent
Staffordshire DE14 2AS
UK

Phone: +44 (0) 1283 531499
Fax: +44 (0) 1283 531548
Email:
europesales@nzpump.com

