



# COVERALL

## READY-TO-USE STERILE SINGLE-USE

Already sterilized by gamma irradiation, these sterile goggles have been especially engineered to guarantee high protection and comfort in controlled environments. The production and packaging are carried out under cleanroom class 7 conditions. The sterilization process complies with ISO 11137 to ensure a SAL value of  $10^{-6}$ .

- + **ADJUSTABLE CLEAN ISOPRENE STRAP, CLEAR OF DUSTS, MICROBES AND GERMS**
- + **OVERFLOW CHUTE FOR LIQUIDS, FLEXIBLE PVC FRAME FOR MORE COMFORT / UPPER & LOWER INDIRECT VENTS**
- + **ANTI-FOG PLATINUM LITE COATING**
- + **3 YEARS OF SHELF LIFE**



### TECHNOLOGIES

PLATINUM LITE

### VERSIONS



PSGCOV2R01



COVACLAVE



COVACLEAN



# COVERALL AUTOCLAVE

## MULTI-USE AUTOCLAVABLE

COVERALL AUTOCLAVE protective goggles is specially designed to guarantee total comfort and optimum protection in controlled environments. Equipped with our exclusive anti-fog and anti-scratch PLATINUM coating on both sides of the lens, our autoclavable multi-use goggles are resistant to high temperature and still fully functional after several autoclaving cycles. Its designs fit over any prescription glasses, ensuring improved eye protection and vision.

- + HIGH FOGGING RESISTANCE
- + AUTOCLAVE COMPATIBLE PRODUCT
- + OVERFLOW CHUTE FOR LIQUIDS
- + PLATINUM COATING : ANTI-SCRATCH & ANTI-FOG



### TECHNOLOGIES

PLATINUM

### VERSIONS



PSGCOV2R01



COVACLAVE



COVACLEAN



# COVERALL CLEAN

## NON-STERILE SINGLE-USE

COVERALL CLEAN protective goggles is specially designed to guarantee total comfort and optimum protection in sensitive and sterile environments such as pharmacies, micro-electronics and operating theatres. Disposable non-sterile goggles that can be treated by the customer by gamma or beta irradiation or by ethylene oxide sterilisation.

- + CAN BE STERILISED USING GAMMA, BETA IRRADIATION OR ETYLENE OXIDE STERILISATION
- + DISPOSABLE
- + ANTI-FOG PLATINUM LITE COATING
- + OVERFLOW CHUTE FOR LIQUIDS



### TECHNOLOGIES

PLATINUM LITE

### VERSIONS



COVERALL



COVACLAVE



COVACLEAN



| COVERALL |         |            |                    |                   |               |             |
|----------|---------|------------|--------------------|-------------------|---------------|-------------|
| USE      | VERSION | REFERENCE  | LENS MARKING       | FRAME MARKING     | COATING       | STANDARD    |
|          | CLEAR   | PSGCOV2R01 | 19 BT C€           | EN166 3 4 9 BT C€ | PLATINUM LITE | EN166       |
|          | CLEAR   | COVACLAVE  | 2C-1.2  1 FT KN C€ | EN166 3 4 FT C€   | PLATINUM      | EN166-EN170 |
|          | CLEAR   | COVACLEAN  | 2C-1.2  1 BT C€    | EN166 3 4 BT C€   | PLATINUM LITE | EN166-EN170 |

| PACKAGING & EAN13 CODE         |                                     |  |
|--------------------------------|-------------------------------------|--|
| SINGLE                         | INNER BOX:                          | OUTER PACK:                              |
| Size: 270 x 130 x 90 mm        | Size: 53x37x10 cm<br>Weight: 0.85 g | Size: 39.8 x 36 x 32 cm<br>Weight: 32 kg |
| <b>3660740011499</b>           | <b>3660740111496</b> -12 pcs        | <b>3660740211493</b> -48 pcs             |
| <b>3660740000646</b>           | <b>3 660 740 100 643</b> -5 pcs     | <b>3 660 740 200 640</b> -90 pcs         |
| <b>3660740007850</b>           | <b>3 660 740 107 857</b> -5 pcs     | <b>3 660 740 207 854</b> -150 pcs        |
| <b>CUSTOM CODE:</b> 9004901000 |                                     |  |

**S:** MODELS IN SMALL SIZE

| PSGCOV2R01 : GENERAL SPECIFICATIONS |   |
|-------------------------------------|---|
| <b>LENS</b>                         | POLYCARBONATE   |
| <b>FRAME</b>                        | PVC - INDIRECT VENTILATED ON THE UPPER PART AND INDIRECT VENTILATED ON THE BOTTOM |
| <b>WEIGHT</b>                       | 66 g  |
| <b>STRAP</b>                        | ISOPRENE - WHITE  |
| <b>USE</b>                          | SINGLE USE - ALREADY STERILIZED   |

| COVACLAVE : GENERAL SPECIFICATIONS |  |
|------------------------------------|--|
| <b>LENS</b>                        | POLYCARBONATE  |
| <b>FRAME</b>                       | TPR - INDIRECT VENTILATED ON THE UPPER PART AND SEALED ON THE BOTTOM |
| <b>WEIGHT</b>                      | 77 g   |
| <b>STRAP</b>                       | ISOPRENE - GREY  |
| <b>USE</b>                         | MULTI USE - AUTOCLAVE  |

| COVACLEAN : GENERAL SPECIFICATIONS |   |
|------------------------------------|---|
| <b>LENS</b>                        | POLYCARBONATE   |
| <b>FRAME</b>                       | PVC - INDIRECT VENTILATED ON THE UPPER PART AND INDIRECT VENTILATED ON THE BOTTOM |
| <b>WEIGHT</b>                      | 94 g  |
| <b>STRAP</b>                       | ISOPRENE - GREY   |
| <b>USE</b>                         | SINGLE USE - STERILISABLE   |



**PSGCOV2R01**  
MADE IN: CN



**COVACLAVE**  
MADE IN: TW



**COVACLEAN**  
MADE IN: TW

**KNOW MORE ABOUT MARKINGS:**

**OR SCAN:**

**CLEANING & STORAGE**

**CLEANING:** The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

**MAINTENANCE:** Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the spectacles or goggles in a microfiber pouch or rigid case.

**STORAGE:** All products must be stored in a dry and clean environment.



DATASHEET : 12-14-2021

**bolle-safety.com**

**Europe Headquarters**  
34 rue de la Soie  
69100 Villeurbanne  
France  
Tél. : 00 33 (0) 4 78 85 23 64

**U.K. & Ireland**  
Unit C83 - Barwell Business Park  
Leatherhead Road - Chessington  
Surrey - KT9 2NY - UK  
Tél. : 00 44 (0)208 391 4700

**USA Office**  
2810 Caribou Court, Suite 160  
Carlsbad, CA 92010  
United States of America  
Tél. : 800 222 6553

**Asia-Pacific Office**  
32-40 Fairchild Street  
heatherton VIC 3202  
Australia  
Tél. : 1300 138 098

