

### P304 - FFP3 Valved Dolomite Light Cup Respirator

**Collection:** Disposable Mask FFP3

**Range:** Disposable Masks

**Materials:** PP

**Inner Pack:** 10

**Outer Carton:** 30

#### Product information

Disposable respirator with a lightweight cup featuring EVA foam under the adjustable nose bridge for extra comfort. Ultrasound welded and metal free, the exhalation valve works efficiently to reduce heat inside the mask and provides comfort when used in hot and humid conditions. DOLOMITE optional test clogging test.

#### Disposable Mask FFP3

Disposable mask FFP3 level, protects against solid and liquid particles of high toxicity. Minimal % of filtration 99%. Protects up to 20 times the TLV (Assigned Protection Factor for FFP3 masks) or up to 50 times TLV (Nominal Protection Factor for FFP3 masks). Examples of applications: Sanding of hard wood (beech, oak) / treatment of wood using copper, chrome or arsenic based products / impact stripping of paint / sanding of cement. Our Biztex brand ensures exceptional quality and performance across our full range of disposable masks.

#### Disposable Masks

Our Biztex™ brand ensures exceptional quality and performance across our full range of disposable masks. The extensive Biztex range offers a high level of protection and quality safeguarding the wearer against many workplace risks including liquid chemicals, static electricity, dry particles and radioactive contamination. The complete Biztex range includes disposable masks and limited-life garments.

#### Standards

EN149:2001+A1:2009 FFP3 (NR D)



#### Features

- CE-CAT III
- Dolomite optional clogging test (D) to provide more comfortable breathing and longer lasting filtration performance
- Large inner space to help the user to breathe more easily
- High performance exhalation valve to reduce heat and provide comfort when used in hot and humid conditions
- Ultrasound welded elastic strap
- Retail box which aids presentation for retail sales

	Range
White	-

# PORTWEST®

## PRODUCT SPECIFICATION & TECHNICAL DATA

### **P304 - FFP3 Valved Dolomite Light Cup Respirator** **Commodity Code: 6307909311**

#### **Test House**

INSPEC International B.V. (Notified Body No.: 2849)

Beechavenue 54-62

1119 PW, Schiphol-Rijk, The Netherlands

Cert No: PPE20162097

#### **CARTON DIMENSIONS/WEIGHT**

Item	Colour	Len	Wid	Hgt	Weight (Kg)	Cubic (m <sup>3</sup> )	EAN13	DUN14
P304WHR	White	67.0	44.0	34.0	0.1990	0.1002	5036108273676	15036108763778