

# TECHNICAL SPECIFICATION



## EVOGuard®C Industrial Browguard Only

EVOGuard®C Industrial Browguard Only / ADB280-000-400



### DESCRIPTION

EVOGuard®C Industrial Browguard for use with \*EVOGuard® visors, providing innovative solutions to protect the wearer in a multitude of high-risk working environments.

The EVOGuard®C Industrial Browguard meets the requirements of EN 166 and EN 1731 when fitted with the appropriate EVOGuard® visor.

\*EVOGuard® C5 Max visor for use with EVO® helmets only.

### OPTIONS

**EVOGuard®C Industrial Browguard Only  
(ADB280-000-400)**

### SAFETY STANDARDS

EN 166 • EN 1731



JSP Limited, Worsham Mill, Minster Lovell, Oxford OX29 0TA, England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jspsafety.com / Web: www.jspsafety.com

Do Not Publish without written permission from JSP Limited. Contact copyright@jspsafety.com. Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

Page 1 of 2 / Issued 30 May 2024 / Copyright 2018 - 2024. JSP Limited. All Rights Reserved.



## SPECIFICATIONS

Harness  
NEW Rake. 6 positions. sizing strap over head.  
Extra long sweat band.



Universal Accessories Slot  
Yes



Wheel Ratchet  
Yes NEW Sprung comfort pad



Integrated Eyewear  
Optional EvoSpec



Recyclable  
Yes



BSI Kitemark  
Yes

Material  
30% Glass Filled Nylon



Product Weight  
210g

## FEATURES



### Compatibility

EVOGuard® visors maximise compatibility with JSP half masks, disposable respirators, prescription glasses and the Sonis® helmet mounted ear defender range.



### Vision

The optical class 1 visor offers a panoramic view with minimal distortion, ideal for comfortable all day wear.



### Impact

Wide range of high performance visors offering up to A rated impact resistance when fitted to a safety helmet and medium energy impact protection with the EVOGuard® browguard.



### Coverage

EVOGuard® visors provide comprehensive facial coverage without limiting movement. EVOGuard® MAX visors offer enhanced coverage with an integral chinguard.



### Supreme Comfort & Fit

Features the new JSP Revolution® wheel ratchet, securely tightening and holding the unit firmly in position, no matter the task or amount of user movement involved. System comes complete with a wraparound, soft foam backed, replaceable, Chamlon™ sweatband offers superior comfort.



### Maximum Adjustability

Multiple fitting positions allow the wearer to adjust the browguard in three ways. An over the crown slide fitting combined with a forward and back adjustment, maximises compatibility with different head shapes.

## APPLICATIONS

General guidance only and should not be considered a substitute for a full risk assessment

Aerospace

Agricultural

Airports

Facilities Management

Food and Drink Manufacturing

Forestry & Landscaping

Hospitals, Healthcare & Pharmaceuticals

Manufacturing

Maritime

## RANGE

## DOWNLOADS



[Image Pack \(ZIP\)](#)

[doc-evoguard.pdf \(PDF\)](#)

JSP Limited, Worsham Mill, Minster Lovell, Oxford OX29 0TA, England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: [sales@jspsafety.com](mailto:sales@jspsafety.com) / Web: [www.jspsafety.com](http://www.jspsafety.com)

Do Not Publish without written permission from JSP Limited. Contact [copyright@jspsafety.com](mailto:copyright@jspsafety.com). Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

Page 2 of 2 / Issued 30 May 2024 / Copyright 2018 - 2024. JSP Limited. All Rights Reserved.

