

(<http://www.impact-test.co.uk>)

Sieve Shaker, Motorised



*for 200, 250, 300 & 315mm,
 8 & 12 inch diameter sieves*

Code SV001
 Weight (kg) 24
 Tariff 847410 00 0

(images/SV001-Motorised-Sieve-Shaker_zoom.jpg)

This is a simple, and low cost Sieve Shaker, ideal for both site and laboratory use.

It incorporates an electric motor to provide an effective sieving action. This unit will accept 200, 250, 300 and 315mm, 8 and 12 inch diameter sieves. The shaker can hold up to eight 200mm diameter sieves or seven 300mm diameter sieves.

It is fitted with a 0 to 60 minute timer. Wet sieving kits in the appropriate sizes may be used with this shaker.

Specification

| | |
|-----------------------|---|
| Sieve sizes accepted: | 200mm, 250mm, 300mm, 315mm diameter 8 inch & 12 inch diameter |
| Timer: | 0 - 60 minutes |
| Rating: | 110W |
| Power supply: | 220-240V 50Hz 1ph |
| Dimensions: | 350 x 400 x 950mm |
| Weight: | 24kg |

A user guide is available to download from the Impact web site www.impact-test.co.uk

Impact Test Equipment Ltd
 Stevenston Industrial Estate
 Stevenston
 Ayrshire
 KA20 3LR
www.impact-test.co.uk

Tel: +44 (0) 1294 602626
 Fax: +44 (0) 1294 461168
 Email: sales@impact-test.co.uk

www.impact-test.com

